

Two Seat Sofa Instruction Manual

Safety Instructions – Please read and retain for future reference.

After unpacking, check the product for signs of transit damage - do not use if damage is found.

Keep away from fire or flammable materials.

Do not stand or put excessive weight on the product, this could cause damage.

If the product has been dropped/damaged cease using it immediately.

The maximum safe weight for use of this product is 400 kilograms.

Check that the product is stable before using it.

Parts of the assembly process will be easier with 2 people.

Only use on an even/level surface.

During assembly children should be kept away from the product due to possible risk of injury.

This product is not intended for use by children below 18 months of age.

Do not allow children to play with or on the product.

This product is to be used solely for domestic purposes.

Suffocation hazard.



WARNING: Children can roll over and get their head or face entrapped against the surface of the product and suffocate.

In The Box

Two Seat Sofa

Sofa Cover

Care and Maintenance

Wipe clean the sofa using a damp cloth and mild detergent. Do not use abrasive cleaners. Never soak or immerse in water.

The use of solvents of any kind on this product may damage the finish.

Cleaning the Sofa Cover

The sofa cover can be removed for washing and easy cleaning, ensure that the below cleaning instructions are adhered to when cleaning.



Machine wash
cold, gentle cycle



Do not bleach



Tumble dry,
delicate




Do not iron

- Avoid the use of harsh cleaning chemicals or bleaches.
- Do not tumble dry or iron.
- Do not wring dry this item.
- Air dry product on a line or surface.

Assembly Instructions

STEP 1: Fully unpack all the contents of the sofa box and allow the Sofa to expand for approximately 24 hours.

STEP 2: Turn the outer cover inside out and align the Velcro strips on the inside of the cover with the Velcro flaps on the inner seat.



STEP 3: Slowly invert the cover and wrap it round the seat, ensuring pressure is placed on the Velcro straps to ensure maximum adhesion (as per images above).

STEP 4: Secure the cover in place using the fastening zip at the base of the sofa. Allow the sofa to settle for 48 hours before using as desired.

NOTE: It is recommended to wash the cover prior to use, to remove all loose threads.

Disposal

This product should not be discarded within household waste. Take to your local recycling station for disposal.

Model Number: HF000157, HF000159

Manufactured by: Online Home Shop LTD, Priestley Road, Manchester, M28 2LX, UK Made in China

For Online Support: support@onlinehomeshop.com

Made in China